


Figure 2







Figure 4



3/3 PLACEMENT AND **DISPLAY GLASS** ICON. UPDATE ORIENTATION DEFAULTS. TIMEOUT OR PAPER **TAKEN AWAY** . 140 USING SETTINGS, 136 PLACEMENT AND ORIENTATION ON CURRENT ICON. UPDATE SETTINGS CHANGED PAPER DETECTED, **OR TIME OUT?** SETTINGS CHANGED, 132 PAPER ON GLASS PLACEMENT AND ORIENTATION. **DISPLAY GLASS** ICON. UPDATE - 0N -PAPER IN ADF 122-PLACEMENT AND ICON. UPDATE ORIENTATION. **DISPLAY ADF**

Figure 5